

Preventing heavy condensation in your suite

Airflow from the corridors into each suite controls humidity. Air should flow through all suites at all times via the bottom of the residential door.

If you sealed the bottom of the door (e.g. with weather-stripping), heavy condensation on your windows, and / or wall mould occurs. **This practice violates the fire protection system.**

To ensure your suite has proper ventilation:

- Ensure air from the corridor flows under your front door.
- Keep a window in your suite open for at least 15 minutes per day - especially after taking a shower, or boiling water (which causes warm, moist air).
- Use the dehumidifier in your suite (normally in your bathroom).
 - Slide the switch to **ON** position. See the Classico Owners' Manual to program it auto-set times (p.34).
- Use your exhaust fans when taking a shower or cooking.
- Keep your suite as cool as possible to reduce condensation.
- Ensure your dryer vent is free from lint.