

NOTICE TO RESIDENTS

WASHING MACHINE OVERFLOW



We again experienced a flood resulting from the malfunction of the water level switch in the washing machine.

The water level switch, located inside the console, is used in controlling the amount of water entering the washer.

A defect or an obstruction in the water level switch may cause water overflow, resulting in extremely costly floods.

To reduce the risk of being financially responsible for the cost of flood damage to other suites, it is essential that you have your washing machine periodically serviced by an appliance technician.

**"CLASSICO" - strata council
22 July, 2013**